## REPLACING THE BATTERY

When removed from a vehicle, the DriveRight unit taps its own battery for power (instead of relying on the vehicle's battery). On the unit's battery alone, a unit will operate for 260 hours or, in sleep mode, 2 months.

The life of the unit's battery depends on your download schedule. For example, if you take the unit out of the vehicle 5 days a week, 8 hours a day, the unit's battery can last up to 9 months. In that situation, because not all out-of-vehicle time will be spent in sleep mode and because of the occasional delay in returning the unit to the vehicle, we recommend replacing the battery every 6 months. If at any time the LCD display begins dimming, the battery is low and due for replacement.

If you plan to store a unit out-of-vehicle for more than a week, we recommend removing the battery. When you replace the battery, data and settings are not lost (though you will need to reset the date and time).

PN: 7395-056A